




HOW TO CONNECT/DISCONNECT HIROSE (G5) CONNECTOR TO/FROM G5/FC200 HANDHELD

Please follow the following steps when connecting/disconnecting the Hirose (G5) connector to and/or from the handheld computer in order to avoid bending or breaking the connector contacts. Following these steps will guarantee an extended life of the optical probe.


A. TO INSERT THE CONNECTOR INTO THE HANDHELD RECEPTACLE



Hold the plug at point A, align the plug guide with the receptacle guide, and push the plug straight. The plug will mate with the receptacle smoothly.

****NOTE: DO NOT PUSH PLUG IN UNTIL PROPERLY ALIGNED****

B. TO REMOVE THE CONNECTOR FROM THE HANDHELD RECEPTACLE



Hold the plug connection sleeve B and pull the sleeve straight. The plug will come off easily.

Corporate Office:
uData Net Corp.
6320 Southwest Blvd., Ste. 205
Fort Worth, Texas 76109
(817) 348-9700 Tele
(817) 348-9701 Facsimile
www.udatanet.com

Manufacturing Office:
uData Net Corp.
3247 N. 38th Street
McAllen, Texas 78501
(956) 631-5300 Tele
(956) 631-5193 Facsimile
www.udatanet.com